
Subject: Phantom power not enabled

Posted by [JoaoMenezes](#) on Wed, 21 Apr 2021 12:01:47 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi All,

I am not able to engage phantom power in any of my channel strips. The button isn't even highlighted, making it seem inactive.

Any suggestions?

I'm running a 3882 3D Expanded with the latest pb10-138 on Catalina (10.15.7)

Best,
JM
