
Subject: LIO-8 Volume Control
Posted by [jtwrace](#) on Tue, 19 Jun 2012 16:08:55 GMT
[View Forum Message](#) <> [Reply to Message](#)

Should the LIO-8 volume be set at "00/0" when using an external preamp?

Subject: Re: LIO-8 Volume Control
Posted by [Allen](#) on Tue, 19 Jun 2012 16:36:00 GMT
[View Forum Message](#) <> [Reply to Message](#)

Yes, assuming you don't need to add any more gain to the output of the external preamp.

Subject: Re: LIO-8 Volume Control
Posted by [jtwrace](#) on Tue, 19 Jun 2012 17:09:57 GMT
[View Forum Message](#) <> [Reply to Message](#)

Allen wrote on Tue, 19 June 2012 12:36 Yes, assuming you don't need to add any more gain to the output of the external preamp.

When set at 00/0 is it in bypass mode? Does it have any affect sonically to have it not at 00/0?

Subject: Re: LIO-8 Volume Control
Posted by [Allen](#) on Tue, 19 Jun 2012 17:30:30 GMT
[View Forum Message](#) <> [Reply to Message](#)

Don't know what you mean by "bypass mode"; the only thing that will change by adjusting the gain is the level of the signal going to the A/D convertor. Simplest thing is to just leave the gain at 0 dB.
