

---

Subject: ULN8 3D power switch no longer functions  
Posted by [recordsmith](#) on Wed, 07 Jul 2021 16:12:24 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

It is weird it just stays on as long as there is power. Is this normal. I don't recall this being the case in the past.

Jon

---

---

Subject: Re: ULN8 3D power switch no longer functions  
Posted by [bj](#) on Wed, 07 Jul 2021 18:12:14 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I can think of three possibilities:

- 1) Only the XLR power port is switched; if you plug the power into the 2.1mm coaxial power port then the front panel power switch is defeated.
- 2) There is a jumper on the power supply board. If you have installed the jumper, it bypasses the power switch
- 3) The switch has failed and needs to be replaced (its possible, but I am not aware of this having happened for any unit in the past).

Check possibilities 1+2. If it isn't one of them, then get in touch with support to get a replacement switch.

---