
Subject: analog 1/2 direct output on 2882 3D
Posted by [greg sextro](#) on Tue, 31 May 2022 17:47:51 GMT
[View Forum Message](#) <> [Reply to Message](#)

UPDATE - just figured this out. Not sure how to delete this post...

Subject: Re: analog 1/2 direct output on 2882 3D
Posted by [bj](#) on Tue, 31 May 2022 18:21:26 GMT
[View Forum Message](#) <> [Reply to Message](#)

it is because they are already assigned to the main monitor out in the monitor controller. You can unassign them in the Mon Out path, or you can delete the Mon Out path; either will release them and make them available for assignment in the mixer.

Please note that by default Analog 1+2 are set to Monitor output level (about -30 dB relative to Line +4); if you will be using these for line out, you should make sure that you set the output levels to Line+4 in the Analog I/O control pane.
